

INSTALLATION INSTRUCTIONS



With hearth tilted on back, bolt together



Remove protective pieces from Ventless firebox



With hearth in place, install firebox



**With firebox in place, now is the time to make ALL GAS connections.
Make sure there is air space between front of firebox & hearth for ventilation**



With all GAS connections made and pressure tested, bolt side sections to hearth. Run wire to switch bolt. Bolt back to side sections.



**Stack and bolt
subsequent sections**



INSTALLATION INSTRUCTIONS

page 5



With chimney in place and bolted together, the Installation is complete.



ALL seams should be grouted with Sanded grout.

After grout is dry, Fireplace should be cleaned and resealed with a flat sheen Penetrating sealer.